70 Mr. Ong Tze Wee

TEST REPORT

KEIWA IN

Client: KEIWA Inc.

Report No.: 33911103-01M- 002

Date Issued:

30/Nov/2006

Date Tested: 15/Nov/2006

Sample Receiving Date:

09/Nov/2006

Subject: Analysis for RoHS/ELV Directive

Authorized by Yoshiharu Namegaya

Manager of Central Research Laboratry
NIHON ENVIRONMENTAL SERVICES CO. LTD.

2-1-13, Sachiura, Kanazawa-ku, Yokohama-shi, Kanagawa-ken, JAPAN TBL +81-45 (780) 3831

Tested by Kouta Kumao

RESULTS ARE REPORTED AS FOLLOWS

Sample Name	Corrosion inhibiting Paper for zînc-coated carbon steel sheets			
Test Item	Results	Quantitation Limit	Unit	Test Method
Cadmium	N.D.	1	ppm	With reference to EPA Method 3052 (Microwave digestion – ICP-MS method)
Lead	N.D.	. 10	mqq	With reference to EPA Method 3052 (Microwave digestion - ICP-MS method)
Mercury	N.D.	1	ppm	With reference to EPA Method 3052 (Microwave digestion - ICP-MS method)
Total Chromium	2	1	mqq	With reference to EPA Method 3052 (Microwave digestion - ICP-MS method)
Bromine	12	2.7	ppm	Energy dispersive X-Ray Fluorescence Spectroscopy (BDXRF)
(End of report)		,		
· · · · · · · · · · · · · · · · · · ·				
				,

ICP-MS; Agilent Technologies, Agilent 7500c

Energy dispersive X-ray fluorescence analyzer; [BOL, [SX 3202EV

Note:

N.D. = Not Detected (Less than Quantitation Limit)

X-ray fluorescence analysis (EDXRF) is screening test method.

·Quantitation limit of Bromine expresses 3 σ value.

The test results are quantitated by calibration curve method.

Measurement time of Bromine is 30 sec.

The results relate only to the items tested.